

Assembly instructions for Aprile door handles and rosettes (Product code: AS R 5S, AS Q 5S)

HANDLES

The set includes:

- a pair of handles - left and right; combined with roses;
- 2 pcs. of mounting roses (so-called mounting adapters);
- handle stem 8x8 mm (two-part);
- 2 pcs. of through bolts M4;
- set of Allen screws with a spanner;
- set of wood screws.

Assembly of the handle:

1. Drill 2 \varnothing 7.5 mm holes on both sides of the door, spacing 38 mm, for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can either use a mounting template to mark the holes or use a mounting adapter with an element stabilising stem. After preparing the screw holes, break out the stem stabiliser from the adapters and join with metal ring.
2. Use the supplied bolts and screw the two mounting adapters together. These elements should be oriented with the safety tab downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws.
4. Fold the stem and insert it into the door lock with the notch facing downwards so that the length of the stem is the same on both sides of the door.
5. Place and press the handle onto the adapter and stem thus installed. The handle shall be flush with the door.
6. Fasten the handles from below with Allen screws.

ROSES OB and PZ

The set includes:

- 2 pcs. rosette covers;
- 2 pcs. of mounting roses (so-called mounting adapters consisting of a metal ring and synthetic part);
- 2 pcs. of through bolts M4;
- a set of wood screws.

Assembly of the rosette:

1. Drill 2 \varnothing 7.5 mm holes on both sides of the door, spacing 38 mm, for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can either use a mounting template to mark the holes or use a mounting adapter with an element stabilising stem. After preparing the screw holes, break out the stem stabiliser from the adapters and join with metal ring.
2. Use the supplied bolts and screw the two mounting adapters together. These elements should be oriented with the safety tab downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws.
4. Place and press the rose onto the adapter thus installed. The rose should fit flush with the door.

WC ROSES

The set includes:

- 2 pcs. rosette covers;
- 2 pcs. of mounting roses (so-called mounting adapters consisting of a metal ring and synthetic part);
- 2 pcs. of through bolts M4;
- a set of Allen screws and spanners
- WC knob with handle stem 4x4 mm (it is possible to order an additional reduction);
- a set of wood screws

Assembly of the rosette:

1. Drill 2 \varnothing 7.5 mm holes on both sides of the door, spacing 38 mm, for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can either use a mounting template to mark the holes or use a mounting adapter with an element stabilising stem. After preparing the screw holes, break out the stem stabiliser from the adapters and join with metal ring.
2. Use the supplied bolts and screw the two mounting adapters together. These elements should be oriented with the safety tab downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws.
4. Place and press the rose onto the adapter thus installed. The rose should fit flush with the door.
5. Slide the stem into the door lock. For magnetic locks, use a reduction to change the diameter of the hole for the W.C. stem.
6. Screw the knob of the W.C. rose to the stem with the Allen screw.

Congratulations! That is all.