

Assembly instructions for Aprile door handles and rosettes (Product code: AS RT 7S, AS RTH 7S)

HANDLE:

The set includes:

- a pair of handles - left and right; combined with roses;
- 2 pcs. of mounting roses (so-called mounting adapters);
- handle stem 8x8 mm (two-part);
- 2 pcs. of through bolts M4;
- set of Allen screws with a spanner;
- set of wood screws

Assembly of the handle:

1. Drill 2 \varnothing 7.5 mm holes on both sides of the door with 38 mm spacing for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can use the assembly template to mark the hole locations.
2. Use the supplied bolts and screw the two mounting adapters together. These elements shall be oriented with the safety notch downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws. Screws are not included.
4. Fold the stem and insert it into the door lock with the notch facing downwards so that the length of the stem is the same on both sides of the door.
5. Place the handle on the adapter and stem thus installed. The handle shall be flush with the door.
6. Screw the handle rose from below to the adapter.
7. Screw the handles from below using Allen screws.

OB ROSES

The set includes:

- 2 pcs. rosette covers;
- 2 pcs. of mounting roses (so-called mounting adapters);
- 2 pcs. of through bolts M4;
- a set of wood screws.

Assembly of the rosette:

1. Drill 2 \varnothing 7.5 mm holes on both sides of the door with 38 mm spacing for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can use the assembly template to mark the hole locations.
2. Use the supplied bolts and screw the two mounting adapters together. These elements shall be oriented with the safety notch downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws. Screws are not included.

4. Place the rose on the mounted adapter and fasten it from below with an Allen screw. The rose should fit flush with the door.

WC ROSES

The set includes:

- 2 pcs. rosette covers;
- 2 pcs. of mounting roses (so-called mounting adapters);
- 2 pcs. of through bolts M4;
- a set of Allen screws and spanners
- WC knob with handle stem 4x4 mm (it is possible to order an additional reduction);
- a set of wood screws.

Assembly of the rosette:

1. Drill 2 \varnothing 7.5 mm holes on both sides of the door with 38 mm spacing for through bolts. Do not drill through the door on one side. Ream the holes on both sides to avoid damaging the outer layer of the door. You can use the assembly template to mark the hole locations.
2. Use the supplied bolts and screw the two mounting adapters together. These elements shall be oriented with the safety notch downwards. The adapters are universal (right/left).
3. You can additionally stabilise the mounting adapters with wood screws. Screws are not included.
4. Place the rose on the mounted adapter and fasten it from below with an Allen screw. The rose should fit flush with the door.
5. Slide the stem into the door lock. For magnetic locks, use a reduction to change the diameter of the hole for the W.C. stem.
6. Screw the knob of the W.C. rose to the stem with the Allen screw

Congratulations! That is all.